

Low-Level C Programming

Prof. Stephen A. Edwards
sedwards@cs.columbia.edu

NCTU, Summer 2005

Low-Level C Programming -- p. 15

Goals

Function is correct
Source code is concise, readable, maintainable
Time-critical sections of program run fast enough
Object code is small and efficient

Basically, optimize the use of three resources:

- Execution time
- Memory
- Development/maintenance time

Low-Level C Programming -- p. 25

Like Writing English

You can say the same thing many different ways and mean the same thing.

There are many different ways to say the same thing.

The same thing may be said different ways.

There is more than one way to say it.

Many sentences are equivalent.

Be succinct.

Low-Level C Programming -- p. 35

Arithmetic

Integer Arithmetic Fastest

Floating-point arithmetic in hardware Slower

Floating-point arithmetic in software Very slow

+ , -
×
÷
sqrt, sin, log, etc.

↓ slower

Low-Level C Programming -- p. 45

Simple benchmarks

```
for (i = 0 ; i < 10000 ; ++i)
  /* arithmetic operation */
```

On my desktop Pentium 4 with good hardware floating-point support,

Operator	Time	Operator	Time
+ (int)	1	+ (double)	5
* (int)	5	* (double)	5
/ (int)	12	/ (double)	10
« (int)	2	sqrt	28
		sin	48
		pow	275

Low-Level C Programming -- p. 55

Simple benchmarks

On my Zaurus SL 5600, a 400 MHz Intel PXA250 Xscale (ARM) processor:

Operator	Time	Operator	Time
+ (int)	1	+ (double)	140
* (int)	1	* (double)	110
/ (int)	7	/ (double)	220
« (int)	1	sqrt	500
		sin	3300
		pow	820

Low-Level C Programming -- p. 65

C Arithmetic Trivia

Operations on `char`, `short`, `int`, and `long` probably run at the same speed (same ALU).

Same for unsigned variants

`int` or `long` slower when they exceed machine's word size.

Operations on `floats` performed in double precision. `float` only useful for reducing memory.

Arithmetic Lessons

Try to use integer addition/subtraction

Avoid multiplication unless you have hardware

Avoid division

Avoid floating-point, unless you have hardware

Really avoid math library functions

Bit Manipulation

C has many bit-manipulation operators.

- & Bit-wise AND
- | Bit-wise OR
- ^ Bit-wise XOR
- ~ Negate (one's complement)
- » Right-shift
- « Left-shift

Plus assignment versions of each.

Bit-manipulation basics

```
a |= 0x4;      /* Set bit 2 */
b &= ~0x4;     /* Clear bit 2 */
c &= ~(1 << 3); /* Clear bit 3 */
d ^= (1 << 5); /* Toggle bit 5 */
e >>= 2;      /* Divide e by 4 */
```

Low Level C Programming - p. 105

Advanced bit manipulation

```
/* Set b to the rightmost 1 in a */
b = a & (a ^ (a - 1));

/* Set d to the number of 1's in c */
char c, d;
d = (c & 0x55) + ((c & 0xaa) >> 1);
d = (d & 0x33) + ((d & 0xcc) >> 2);
d = (d & 0x0f) + ((d & 0xf0) >> 4);
```

Low Level C Programming - p. 115

Faking Multiplication

Addition, subtraction, and shifting are fast. Can sometimes supplant multiplication. Like floating-point, not all processors have a dedicated hardware multiplier. Recall the multiplication algorithm from elementary school, but think binary:

```
  101011
   × 1101
  -----
  101011
 10101100
+101011000
-----
1000101111

= 43 + 43 << 2 + 43 << 3 = 559
```

Low Level C Programming - p. 155

Faking Multiplication

Even more clever if you include subtraction:

```
  101011
   × 1110
  -----
  1010110
 10101100
+101011000
-----
1001011010

= 43 << 1 + 43 << 2 + 43 << 3
= 43 << 4 - 43 << 2
= 602
```

Only useful

- for multiplication by a constant
- for "simple" multiplicands
- when hardware multiplier not available

Low Level C Programming - p. 135

Faking Division

Division is a much more complicated algorithm that generally involves decisions. However, division by a power of two is just a shift:

```
a / 2 = a >> 1
a / 4 = a >> 2
a / 8 = a >> 3
```

There is no general shift-and-add replacement for division, but sometimes you can turn it into multiplication:

```
a / 1.33333333
= a * 0.75
= a * 0.5 + a * 0.25
= a >> 1 + a >> 2
```

Low Level C Programming - p. 145

Multi-way branches

```
if (a == 1)      switch (a) {
    foo();        case 1:
                  foo(); break;
else if (a == 2) case 2:
    bar();        bar(); break;
else if (a == 3) case 3:
    baz();        baz(); break;
else if (a == 4) case 4:
    qux();        qux(); break;
else if (a == 5) case 5:
    quux();       quux(); break;
else if (a == 6) case 6:
    corge();      corge(); break;
}
```

Low Level C Programming - p. 155

Microblaze code for if-then-else

```
lwi    r3,r19,44 # fetch "a" from stack
addik  r18,r0,1  # load constant 1
cmp    r18,r18,r3 # compare with "a"
bnei   r18,$L3   # skip if not equal
brlid  r15,foo   # call foo
nop    # delay slot
bri    $L4      # branch to end

$L3:
lwi    r3,r19,44 # fetch "a" from stack
addik  r18,r0,2  # load constant 2
cmp    r18,r18,r3 # compare with "a"
bnei   r18,$L5   # skip if not equal
brlid  r15,bar   # call bar
nop    # delay slot
bri    $L4      # branch to end

$L5:
```

Microblaze code for switch (1)

```
addik  r3,r22,-1
xori   r18,r3,5
bgei   r18,$L0
blti   r3,$L14   # Skip if less than 1
bri    $L1
$L0:
rsubik r18,r3,5
blti   r18,$L14 # Skip if greater than 6
$L1:
addk   r3,r3,r3 # Multiply by four
addk   r3,r3,r3
lwi    r3,r3,$L21 # Fetch address from table
bra    r3
.sdata2
$L21:
.gpword $L15
.gpword $L16
.gpword $L17
.gpword $L18
.gpword $L19
.gpword $L20
```

Microblaze code for switch (2)

```
.text
$L15: # case 1:
brlid  r15,foo
nop
bri    $L14
$L16: # case 2:
brlid  r15,bar
nop
bri    $L14
$L17: # case 3:
brlid  r15,baz
nop
bri    $L14
$L18: # case 4:
brlid  r15,qux
nop
bri    $L14
$L19: # case 5:
brlid  r15,quux
nop
```

Computing Discrete Functions

There are many ways to compute a “random” function of one variable:

```
/* OK, especially for sparse domain */
if (a == 0) x = 0;
else if (a == 1) x = 4;
else if (a == 2) x = 7;
else if (a == 3) x = 2;
else if (a == 4) x = 8;
else if (a == 5) x = 9;
```

Low Level C Programming – p. 195

Computing Discrete Functions

```
/* Better for large, dense domains */
switch (a) {
case 0: x = 0; break;
case 1: x = 4; break;
case 2: x = 7; break;
case 3: x = 2; break;
case 4: x = 8; break;
case 5: x = 9; break;
}
```

```
/* Best: constant-time lookup table */
int f[] = {0, 4, 7, 2, 8, 9};
x = f[a]; /* assumes 0 <= a <= 5 */
```

Low Level C Programming – p. 205

Function calls

Modern processors, especially RISC, strive to make this cheap. Arguments passed through registers. Still has noticeable overhead.

Calling, entering, and returning on the Microblaze:

```
int foo(int a, int b) {
    int c = bar(b, a);
    return c;
}
```

Low Level C Programming – p. 215

Code for foo()

```
foo:
    # Function prologue:
    addik r1,r1,-40 # Update frame pointer
    sw    r15,r0,r1 # Save calling address (r15)

    add   r3,r5,r0 # Swap r5 (a) and r6 (b)
    add   r5,r6,r0 # using r3 as temp
    brlid r15,bar # call bar()
    add   r6,r3,r0 # delay slot: executes before

    # Function epilog:
    lw    r15,r0,r1 # retrieve return address
    rtsd  r15,8     # return to caller
    addik r1,r1,40 # delay slot: release frame
```

Low Level C Programming – p. 225

Strength Reduction

Why multiply when you can add?

```
struct {
    int a;
    char b;
    int c;
} foo[10];
int i;
for (i=0 ;
     i<10 ;
     ++i) {
    foo[i].a = 77;
    foo[i].b = 88;
    foo[i].c = 99;
}

struct {
    int a;
    char b;
    int c;
} *fp, *fend, foo[10];
fend = foo + 10;
for (fp = foo ;
     fp != fend ;
     ++fp) {
    fp->a = 77;
    fp->b = 88;
    fp->c = 99;
}
```

Good optimizing compilers do this automatically.

Low Level C Programming – p. 235

Unoptimized array code (fragment)

```

$L3:
    lwi    r3,r19,28 # fetch i from stack
    addik  r18,r0,9
    cmp    r18,r18,r3
    blei  r18,$L6
    bri    $L4 # exit if i > 9
$L6:
    lwi    r5,r19,28 # fetch i from stack
    addik  r6,r0,12 # compute i * 12
    brlid  r15,mulsi3_proc
    nop
    addik  r4,r0,foo # foo + i * 12
    addk   r3,r4,r3
    addik  r4,r0,77
    sw     r4,r0,r3 # foo[i].a = 77
    lwi    r5,r19,28 # fetch i from stack
    addik  r6,r0,12 # compute i * 12
    brlid  r15,mulsi3_proc
    nop
    addik  r4,r0,foo # foo + i * 12
    addk   r3,r3,r4
    addik  r4,r0,88
    sbi    r4,r3,4 # foo[i].b = 88
```

Low Level C Programming – p. 245

Unoptimized pointer code (fragment)

```

$L8:
    lw     r3,r0,r19
    lwi    r4,r19,4
    rsubk  r18,r4,r3 # fp == fend?
    bnei  r18,$L11
    bri    $L9
$L11:
    lw     r3,r0,r19
    addik  r4,r0,77
    sw     r4,r0,r3 # fp->a = 77
    lw     r3,r0,r19
    addik  r4,r0,88
    sbi    r4,r3,4 # fp->b = 88
    lw     r3,r0,r19
    addik  r4,r0,99
    swi    r4,r3,8 # fp->c = 99
    lw     r3,r0,r19
    addik  r4,r3,12
    sw     r4,r0,r19 # ++fp (stacked)
    bri    $L8
$L9:
```

Optimized array code

```

    addik  r4,r0,foo # get address of foo
    addik  r6,r0,77 # save constant
    addik  r5,r4,108 # r5 has end of array
$L6:
    addik  r3,r0,88
    sbi    r3,r4,4 # foo[i].b = 88
    addik  r3,r0,99
    sw     r6,r0,r4 # foo[i].a = 77
    swi    r3,r4,8 # foo[i].c = 99
    addik  r4,r4,12 # next array element
    cmp    r18,r5,r4 # hit foo[10]?
    blei  r18,$L6
```

Optimized pointer code

```

    addik  r4,r0,foo+120 # fend = foo + 10
    addik  r3,r4,-120 # fp = foo
    rsubk  r18,r4,r3 # fp == fend?
    beqi  r18,$L14 # never taken
    addik  r7,r0,77 # load constants
    addik  r6,r0,88
    addik  r5,r0,99
$L12:
    sbi    r6,r3,4 # fp->b = 88
    sw     r7,r0,r3 # fb->a = 77
    swi    r5,r3,8 # fb->c = 99
    addik  r3,r3,12 # ++fp
    rsubk  r18,r4,r3 # fp == fend?
    bnei  r18,$L12
$L14:
    rtsd  r15,8 # return
    nop
```

How Rapid is Rapid?

How much time does the following loop take?

```
for ( i = 0 ; i < 1024 ; ++i) a += b[i];
```

Operation	Cycles per iteration
Memory read	2 or 7
Addition	1
Loop overhead	≈4
Total	6–12

The Microblaze runs at 50 MHz, one instruction per cycle, so this takes

$$6 \cdot 1024 \cdot \frac{1}{50\text{MHz}} = 0.12\mu\text{s} \text{ or } 12 \cdot 1024 \cdot \frac{1}{50\text{MHz}} = 0.24\mu\text{s}$$

Low-Level C Programming – p. 285

Double-checking

GCC generates great code with -O7:

```
sumarray:
    addik    r1,r1,-24    # create frame
    add     r4,r0,r0     # a = 0
    addik    r6,r5,4092  # end of array

$L6:
    lw      r3,r0,r5     # b[i]      2-7
    addik   r5,r5,4      # ++i      1
    addik   r4,r4,r3     # a += b[i] 1
    cmp     r18,r6,r5    # i < 1024 1
    blei   r18,$L6      3

    add     r3,r4,r0     # return a
    rtsd   r15,8
    addik   r1,r1,24    # release frame
```

Low-Level C Programming – p. 285

Features in order of increasing cost

1. Integer arithmetic
2. Pointer access
3. Simple conditionals and loops
4. Static and automatic variable access
5. Array access
6. Floating-point with hardware support
7. Switch statements
8. Function calls
9. Floating-point emulation in software
10. Malloc() and free()
11. Library functions (sin, log, printf, etc.)
12. Operating system calls (open, sbrk, etc.)

Low-Level C Programming – p. 305

Storage Classes in C

```
/* fixed address: visible to other files */
int global_static;
/* fixed address: only visible within file */
static int file_static;

/* parameters always stacked */
int foo(int auto_param)
{
    /* fixed address: only visible to function */
    static int func_static;
    /* stacked: only visible to function */
    int auto_i, auto_a[10];
    /* array explicitly allocated on heap */
    double *auto_d =
        malloc(sizeof(double)*5);

    /* return value in register or stacked */
    return auto_i;
}
```

Low-Level C Programming – p. 315

Dynamic Storage Allocation



Low-Level C Programming – p. 325

Dynamic Storage Allocation

Rules:

- Each allocated block contiguous (no holes)
- Blocks stay fixed once allocated

malloc()

- Find an area large enough for requested block
- Mark memory as allocated

free()

- Mark the block as unallocated

Low-Level C Programming – p. 335

Simple Dynamic Storage Allocation

Maintaining information about free memory

Simplest: Linked list


The algorithm for locating a suitable block

Simplest: First-fit


The algorithm for freeing an allocated block

Simplest: Coalesce adjacent free blocks

Dynamic Storage Allocation



Simple Dynamic Storage Allocation



Storage Classes Compared

On most processors, access to automatic (stacked) data and globals is equally fast.

Automatic usually preferable since the memory is reused when function terminates.

Danger of exhausting stack space with recursive algorithms. Not used in most embedded systems.

The heap (malloc) should be avoided if possible:

- Allocation/deallocation is unpredictably slow
- Danger of exhausting memory
- Danger of fragmentation

Best used sparingly in embedded systems

Low Level C Programming – p. 375

Memory-Mapped I/O

“Magical” memory locations that, when written or read, send or receive data from hardware.

Hardware that looks like memory to the processor, i.e., addressable, bidirectional data transfer, read and write operations.

Does not always behave like memory:

- Act of reading or writing can be a trigger (data irrelevant)
- Often read- or write-only
- Read data often different than last written

Low Level C Programming – p. 385

With the Microblaze

Xilinx supplies a library of I/O operations:

```
#include "xbasic_types.h"
#include "xio.h"
```

```
XIo_In8(XIo_Address address)
XIo_In16(XIo_Address address)
XIo_In32(XIo_Address address)
void XIo_Out8(XIo_Address address,
             Xuint8 data)
void XIo_Out16(XIo_Address address,
              Xuint16 data)
void XIo_Out32(XIo_Address address,
              Xuint32 data)
```

Each is a simple macro, e.g.,

```
#define XIo_Out32(Addr, Value) \
    { (*(volatile Xuint32 *) (Addr) = Value); }
```

volatile warns compiler not to optimize it

Low Level C Programming – p. 385

An example

```
#include "xbasic_types.h"
#include "xio.h"

int main()
{
    int i, j;
    print("Hello World!\r\n");

    for(j=0;j<256;j++)
        for(i=0;i<100000;i++){
            XIo_Out32(0xFEFF0200, j<<24);
            XIo_Out32(0xFEFF0204, j<<24);
            XIo_Out32(0xFEFF0208, j<<24);
            XIo_Out32(0xFEFF020C, j<<24);
        }

    print("Goodbye\r\n");
    return 0;
}
```

Low Level C Programming – p. 405

HW/SW Communication Styles

Memory-mapped I/O puts the processor in charge: only it may initiate communication.

Typical operation:

- Check hardware conditions by reading “status registers”
- When ready, send next “command” by writing control and data registers
- Check status registers for completion, waiting if necessary

Waiting for completion: “polling”

“Are we there yet?” “No.” “Are we there yet?” “No”

“Are we there yet?” “No” “Are we there yet?” “No”

Low Level C Programming – p. 415

HW/SW Communication: Interrupts

Idea: have hardware initiate communication when it wants attention.

Processor responds by immediately calling an interrupt handling routine, suspending the currently-running program.

Low Level C Programming – p. 425

Unix Signals

The Unix environment provides “signals,” which behave like interrupts.

```
#include <stdio.h>
#include <signal.h>
```

```
void handleint() {
    printf("Got an INT\n");
    /* some variants require this */
    signal(SIGINT, handleint);
}
```

```
int main() {
    /* Register signal handler */
    signal(SIGINT, handleint);
    /* Do nothing forever */
    for (;;) { }
    return 0;
}
```

UART interrupts on the Microblaze

```
#include "xbasic_types.h"
#include "xio.h"
#include "xintc_l.h"
#include "xuartlite_l.h"
#include "xparameters.h"

int main()
{
    XIntc_RegisterHandler(
        XPAR_INTC_BASEADDR, XPAR_MYUART_DEVICE_ID,
        (XInterruptHandler)uart_handler, (void *)0);
    XIntc_mEnableIntr(
        XPAR_INTC_BASEADDR,
        XPAR_MYUART_INTERRUPT_MASK);
    XIntc_mMasterEnable( XPAR_INTC_BASEADDR );
    XIntc_Out32(XPAR_INTC_BASEADDR +
               XIN_MER_OFFSET,
               XIN_INT_MASTER_ENABLE_MASK);
    microblaze_enable_interrupts();
    XUartLite_mEnableIntr(XPAR_MYUART_BASEADDR);
}
```


UART interrupts on the Microblaze

```
#include "xbasic_types.h"
#include "xio.h"
#include "xparameters.h"
#include "xuartlite_l.h"

void uart_handler(void *callback)
{
    Xuint32 IsrStatus;
    Xuint8 incoming_character;
    IsrStatus = XIo_In32(XPAR_MYUART_BASEADDR +
                       XUL_STATUS_REG_OFFSET);

    if ((IsrStatus &
        (XUL_SR_RX_FIFO_FULL |
         XUL_SR_RX_FIFO_VALID_DATA)) != 0) {
        incoming_character =
            (Xuint8) XIo_In32( XPAR_MYUART_BASEADDR +
                             XUL_RX_FIFO_OFFSET );
    }
    if ((IsrStatus & XUL_SR_TX_FIFO_EMPTY) != 0)
        /* output FIFO empty: can send next char */
}
```

Debugging Skills




Low Level C Programming -- p. 485

The Edwards Way to Debug

1. Identify undesired behavior
2. Construct linear model for desired behavior
3. Pick a point along model
4. Form desired behavior hypothesis for point
5. Test
6. Move point toward failure if point working, away otherwise
7. Repeat #4–#6 until bug is found

Low Level C Programming -- p. 475

The Xilinx Tool Chain



Low Level C Programming -- p. 485

The .mhs File

Xilinx *platgen* uses this to piece together the netlist from library components. Excerpt:

```
PORT VIDOUT_GY = VIDOUT_GY, DIR = OUT, VEC = [9:0]
PORT VIDOUT_BCB = VIDOUT_BCB, DIR = OUT, VEC = [9:0]
PORT FPGA_CLK1 = FPGA_CLK1, DIR = IN
PORT RS232_TD = RS232_TD, DIR=OUT
```

```
BEGIN microblaze
PARAMETER INSTANCE = mymicroblaze
PARAMETER HW_VER = 2.00.a
PARAMETER C_USE_BARREL = 1
END
```

```
BEGIN oph_uartlite
PARAMETER INSTANCE = myuart
PARAMETER C_CLK_FREQ = 50_000_000
PARAMETER C_BASEADDR = 0xFEFF0100
PARAMETER C_HIGHADDR = 0xFEFF01FF
END
```

Low Level C Programming -- p. 485

The .mss File

Used by Xilinx *libgen* to link software. Excerpt:

```
BEGIN PROCESSOR
PARAMETER HW_INSTANCE = mymicroblaze
PARAMETER DRIVER_NAME = cpu
PARAMETER DRIVER_VER = 1.00.a
PARAMETER EXECUTABLE = hello_world.elf
PARAMETER COMPILER = mb-gcc
PARAMETER ARCHIVER = mb-ar
PARAMETER DEFAULT_INIT = EXECUTABLE
PARAMETER STDIN = myuart
PARAMETER STDOUT = myuart
END
```

```
BEGIN DRIVER
PARAMETER HW_INSTANCE = myuart
PARAMETER DRIVER_NAME = uartlite
PARAMETER DRIVER_VER = 1.00.b
PARAMETER LEVEL = 1
END
```

Low Level C Programming -- p. 505

The .ucf file

Pin assignments and other global chip information.

```
net sys_clk period = 18.000;
net pixel_clock period = 36.000;
```

```
net VIDOUT_GY<0> loc="p9" ;
net VIDOUT_GY<1> loc="p10";
net VIDOUT_GY<2> loc="p11";
```

```
net VIDOUT_BCB<0> loc="p42";
net VIDOUT_BCB<1> loc="p43";
net VIDOUT_BCB<2> loc="p44";
```

```
net FPGA_CLK1 loc="p77";
```

```
net RS232_TD loc="p71";
```

Low Level C Programming -- p. 515